



Manual
for
Storage Tent PRO
4m Series PVC

DANCOVER[®]

.com

Safety Advice

Attention

In some countries approval is needed to set up a marquee/tent larger than 75 m². It is your responsibility to comply with local rules and regulations and to ensure that the marquee/tent is assembled correctly.

In case of bad weather conditions, it is your responsibility to ensure the marquee/tent is safely secured and that the marquee/tent does not cause damage to others.

Do not use open fire, welding equipment or other sources which can ignite, inside or close to the tent.

The marquee/tent must be safely secured. We recommend you secure your marquee/tent with straps and pegs as soon as it is assembled.

Make sure to check if the marquee/tent is covered by your home contents insurance.

Marquees/tents must be evacuated under extreme weather conditions.

In the event of snow, always remove snow from the roof of the marquee/tent regularly to prevent snow from building on the roof, as heavy snow can cause the marquee/tent to collapse.

In the event of rain, there is a risk of rain puddles building up on top of the roof of the marquee/tent. Heavy rain puddles can cause the roof to collapse. It is your responsibility to ensure rain puddles do not build up. As a precaution, make sure the roof of the marquee/tent is stretched out properly and adequately over the side frames of the marquee/tent and remove rain water regularly.

Do not unpack or repack your marquee/tent in freezing temperatures. In case of temperatures below zero, always unpack and repack your marquee/tent indoors to avoid the risk of cracking parts.

The marquee/tent must be totally dry before you repack and store it to avoid mildew.

Note: Marquees are intended for events and other arrangements and are as such only meant for short term temporary assembly and the following disassembly. Dancover warranty applies only to the normal use of the Product, normal wear and tear excepted, in accordance with written use instructions or manual. The warranty does not apply to damage caused by accident, abuse, misuse, or modification of the Product.

Warranty Information

Please visit dancovershop.com for information on warranty.

Please always check our website for the latest safety advice and manual.
















DANCOVER[®]














.com


















Warning









1. In order to avoid being rusted by air, oil is covered on the surface of the pipes. Before setting up the tent, please remove the oil carefully first to keep the cover clean.
2. Take note that the tent needs to be handled carefully to avoid damage.
3. Do not force the frames as they may be damaged in the process.
4. Tents are meant as temporary shelter, and must be evacuated under extreme weather conditions.

Please, select a suitable site for the tent to avoid the damage of underground sprinkler systems, water, gas or electrical lines.

Part no.			4x10m	4x12m
1	Middle leg 1600mm 50-50		4	6
2	Frame pole 1880mm 38-38		39	46
3	Frame pole 1780mm 50-50		12	14
4	Frame pole 2030mm 50-50		8	10
5	Ceiling rail 2025mm 32-32		2	2
6	Diagonal support 1720mm 32-32		6	6
7	Roof support 1730mm 25-25		6	7
8	Frame pole 2030mm 50-50		4	4
9	Diagonal support 800mm 32-32		4	4
10	Female doorbar 2025mm 32-32		2	2
11	Lower leg 1600mm 50-50		8	8
12	Strengthen bar 1480mm 32-32		2	2
13	Strengthen bar 1845mm 32-32		2	2
A	3-way connector 54-42/3 rings		6	6
B	4-way connector 54-42/4 rings		12	15


Part no.			4x10m	4x12m
14	3-way connector 54-42		4	4
15	4-way connector 54-42		8	10
16	3-way connector for corner		2	2
17	3-way connector for corner		2	2
18	3-way connector for sidewall		8	10
19	2-way connector for endwall		2	2
20	Ceiling rail 1430mm 32-32		2	2
21	Bracket		12	14
22	Groundbracket		10	12
23	Strengthen bar 1855mm 25-25		20	24
24	Turnbuckle for door 5130mm		4	4
25	Turnbuckle for roof 2840mm		20	24
26	Turnbuckle for side 3870mm		20	24

Part no.			4x10m	4x12m
27	Peg 10x350mm		20	24
28	Spiral peg		4	4
29	Small peg		28	32
30	Bungeeball long		60	60
31	M6 wingnut		25	27
32	Screw M6x30mm		12	14
33	Screw M6x45mm		11	11
34	Screw M6x65mm		2	2
35	M6 nut		4	4
36	Spanner		2	2
37	Tie down		4	4
38	Steel clip		70	82
39	Screw M8x50mm		78	92
40	Screw M8x65mm		82	94
41	M8 nut		160	186
42	Peg 16x600mm		18	22
43	M12 washer		4	4

Part no.			4x10m	4x12m
44	M12 nut		4	4
45	Screw M12x48mm		2	2
46	Screw M12x65mm		2	2
47	Sheaved block 1 wheel		2	2
48	Sheaved block 2 wheel		2	2
49	Ratchet stape		4	4
50	Roof		1	1
51	Endwall		2	2


I

Select a flat surface at ground for the tent, unpack the carton and check all the parts including tubes, tent and accessories... etc. are present and the same as the list.
Assemble the framework of rooftop by joining the portion (A, B) together with poles (2, 4, 8) NO. 11 is on four corners for diagonal pipe.




II

To ensure the screw fixed to every pole tightly. And then use the turnbuckle set which is diagonally across through each section as below.




III

Attach one end of supported pole (3) to the joints.
If you want the rope pull at the opposite side than shown in the drawing then switch sheaved block (47) and (48)




IV

Attach the other supported poles (1, 2, 11) to the joints, built-up the framework. NO. 11 is on four corners for diagonal pipe.




V

You facilitate the assembly and dismantling by pulling the roof with ropes on tent frame. Use the steel clips to fasten the cover to the frame. Each section we offer bracket and nail to fasten the frame to ground.



VI

Spread the wall panel and door panel attach to framework by using the bungee cords clasping the frame to grommets that is construct over the wall panel and door panel to ensure stability. Also use the short pegs to fix the doors to the ground.



DANCOVER[®]



Contact information

Head office:

Dancover A/S
Nordre Strandvej 119 G
3150 Hellebæk
Denmark

For more information
please visit:
www.dancovershop.com

National contact

Denmark: 70 26 76 20
denmark@dancover.com

UK: 020 8099 7570
uk@dancover.com

Germany: 041 0266 7040
germany@dancover.com

France: 0975 181 800
france@dancover.com

Sweden: 040 233 262
sverige@dancover.com

Finland: 0 931 581 720
suomi@dancover.com

Poland: 22 300 8602
polska@dancover.com

Luxembourg: +49 041 0266 7040
luxembourg@dancover.com

Portugal: 308 800 899
portugal@dancover.com

Spain: 911 436 828
espana@dancover.com

Italy: 02 479 21 198
italia@dancover.com

Switzerland: 0840 000125
schweiz@dancover.com

Austria: 0662 626935
austria@dancover.com

Norway: 231 00 690
norge@dancover.com

Nederland: 0 858 880 524
nederland@dancover.com

Ireland: 0 151 33 003
ireland@dancover.com

Belgium: 0 28 08 08 09
belgique@dancover.com